

Perfect Shutters, inc.

12213 Highway 173 - Hebron, IL 60034
1-800-548-3336

Painting Instructions **(FOR WOOD AND COMPOSITE ONLY)**

DO NOT ALLOW NATURAL OR PRIMED SHUTTERS TO BE EXPOSED TO OUTDOOR ELEMENTS BEFORE GETTING PAINTED.

BOTH FRONT, BACK & SIDES OF THE SHUTTERS MUST BE PAINTED TO SEAL THE WOOD AND COMPOSITE!

- **NATURAL WOOD AND COMPOSITE.**
 - Lightly sand with a fine grit sand paper or sanding sponge.
 - Dust off all loose dust.
 - Spray or brush a coat of wood primer. (Oil or Water base, Latex, is okay)
 - Let dry per instructions of primer manufacturer.
 - Sand until smooth.
 - Clean off dust.
 - Spray or brush a coat of paint (Oil or Water base, Latex, is okay).
 - Let dry per instructions of paint manufacturer.
 - Sand until smooth.
 - Clean off dust.
 - Spray or brush a second coat of paint.
 - Allow paint to cure per paint manufacturer's instructions prior to installing.

DO NOT LEAN SHUTTERS AGAINST ONE ANOTHER EVEN IF THE PAINT FEELS DRY. THEY CAN STICK TOGETHER!

- **PRIMED WOOD AND COMPOSITE.**
 - Sand until smooth.
 - Clean off dust.
 - Spray or brush a coat of paint (Oil or Water base, Latex, is okay).
 - Let dry per instructions of paint manufacturer.
 - Sand until smooth.
 - Clean off dust.
 - Spray or brush a second coat of paint.
 - Allow paint to cure per paint manufacturer's instructions prior to installing.

DO NOT LEAN SHUTTERS AGAINST ONE ANOTHER EVEN IF THE PAINT FEELS DRY. THEY CAN STICK TOGETHER!